

VEHICLE AIR CONDITIONER AND VEHICLE VENTILATION SYSTEM

CROSS REFERENCE TO RELATED APPLICATION

This application is base on Japanese Patent Application No.
5 2003-46124 filed on February 24, 2003, the disclosure of which
is incorporated herein by reference.

BACKGROUND OF THE INVENTION

1. Field of the Invention:

10 The present invention relates to a vehicle air conditioner
and a vehicle ventilation system, which are operated while a vehicle
stops.

2. Description of Related Art:

15 An automatic ventilation system for a vehicle, which is used
while the vehicle stops, is proposed in JP-A-2000-142089. In this
system, a temperature sensor is used in order to detect a temperature
in a passenger compartment. If the detected temperature is higher
than a predetermined value, a blower is automatically operated
and ventilates the passenger compartment.

20 Generally, a dashboard is heated by sunlight entering into
the passenger compartment, for example, in the daytime in summer.
Thus, if a thermistor inside the dashboard is used as the temperature
sensor, the heated dashboard affects a temperature detection of
the thermistor because an air temperature inside the dashboard
25 increases.

In order to detect a temperature in the passenger compartment
correctly, it is possible to blow air toward the temperature sensor

by a blower whenever the temperature sensor detects a temperature. However, in this case, large energy is consumed because the blower is operated. Therefore, if the ventilation system ventilates the passenger compartment for a long time while the vehicle stops, all energy of a battery may be spent.

SUMMARY OF THE INVENTION

In view of the foregoing problems, it is an object of the present invention to provide a vehicle ventilation system which reduces energy consumption and accurately determines a timing to start ventilating a passenger compartment while a vehicle stops.

It is another object of the present invention to provide a vehicle air conditioner which reduces energy consumption and accurately determines a timing to start air conditioning control of a passenger compartment while a vehicle stops.

According to an aspect of the present invention, a vehicle ventilation system includes a ventilating unit, a non-contact temperature sensor and a ventilation determining means. The ventilating unit ventilates a passenger compartment while a vehicle stops. The non-contact temperature sensor detects infrared rays radiated from a predetermined area of the passenger compartment in non-contact and determines a surface temperature of the predetermined area based on the infrared rays. The ventilation determining means determines whether a ventilation by the ventilating unit is started based on the surface temperature detected by the non-contact temperature sensor. Because the non-contact temperature sensor is used in the vehicle ventilation

system according to the present invention. Therefore, it is not necessary to blow air from the passenger compartment to the non-contact temperature sensor when a temperature in the passenger compartment is detected. Thus, energy consumption due to air blowing can be prevented while the temperature in the passenger compartment can be accurately detected. Accordingly, the vehicle ventilation system can accurately determine the timing to start ventilating by the ventilating unit while energy consumption can be reduced.

According to another aspect of the present invention, an air conditioner for a vehicle includes an air conditioning unit which controls an air condition in a passenger compartment while the vehicle stops, a non-contact temperature sensor which detects infrared rays radiated from a predetermined area of the passenger compartment and detects a surface temperature in the predetermined area in non-contact based on the detected infrared rays, and an air-conditioning determining means which determines whether an air conditioning control by the air conditioning unit needs to be started based on the surface temperature detected by the non-contact temperature sensor. Therefore, the vehicle air conditioner can accurately determine whether air conditioning control by the air conditioning unit needs to be started while energy consumption can be reduced.

Preferably, the ventilation system further includes a reservation means which reserves to perform the ventilation by the ventilating unit in advance. Similarly, the air conditioner includes a reservation means which reserves to perform the air

conditioning by the air conditioning unit in advance. Alternatively, the ventilation system or the air conditioner includes a distance determining means for determining a distance between a user and the vehicle. In this case, the distance
5 determining means determines an approach of the user to the vehicle based on the detected distance between the user and the vehicle when the detected distance between the user and the vehicle is smaller than a predetermined value, and the ventilation determining means or the air-conditioning determining means determines whether
10 the ventilation by the ventilating unit or the air conditioning by the air conditioning unit needs to be started when the distance determining means determines the approach of the user.

More preferably, in the ventilation system or the air conditioner, the non-contact temperature sensor detects a surface
15 temperature in the predetermined area including a seat in the passenger compartment in non-contact. Therefore, the ventilation or the air conditioning can be performed to be fitted to the thermal feeling of the passenger.

According to a further aspect of the present invention, a
20 control system for controlling a vehicle air conditioner or a ventilation system while a vehicle is stopped, includes a determining means that determines whether an air conditioning control by an air conditioning unit or a ventilation control by a ventilation unit needs to be started based on a surface temperature
25 detected by a non-contact temperature sensor. Thus, while the vehicle stops, the control system accurately determines a timing to start the air conditioning control or the ventilation control

of the passenger compartment while energy consumption can be effectively reduced.

BRIEF DESCRIPTION OF THE DRAWINGS

5 Additional objects and advantages of the present invention will be more readily apparent from the following detailed description of preferred embodiments when taken together with the accompanying drawings, in which:

10 FIG. 1 is a schematic diagram showing an entire system of a vehicle air conditioner according to a first embodiment of the present invention;

FIG. 2 is a front view showing an air-conditioning operation panel in FIG. 1;

15 FIG. 3 is a front view showing an arrangement of inside air temperature sensors in FIG. 1;

FIG. 4 is a perspective view showing the arrangement of the inside air temperature sensors in FIG. 1;

FIG. 5 is a perspective view showing a detection area of each of the inside air temperature sensors in a passenger compartment;

20 FIG. 6 is a flowchart showing an air-conditioning operation of an A/C ECU in FIG. 1 in the first embodiment of the present invention;

FIG. 7 is a characteristic graph for determining blower voltage in the first embodiment of the present invention;

25 FIG. 8 is a characteristic graph for determining an air outlet mode in the first embodiment of the present invention;

FIG. 9 is a characteristic graph for determining an opening

degree of an inside-outside air switching door in the first embodiment of the present invention; and

FIG. 10 is a flowchart showing an air-conditioning operation of an A/C ECU according to a second embodiment of the present invention.

DETAILED DESCRIPTION OF THE PRESENTLY PREFERRED EMBODIMENTS

Preferred embodiments of the present invention will be described hereinafter with reference to the accompanying drawings.

(First Embodiment)

The first embodiment of the present invention will be now described with reference to FIGS. 1-9.

In the first embodiment of the present invention, an air conditioner is typically used for performing an air-conditioning in a passenger compartment of a hybrid vehicle which has both an engine and an electric motor for driving. The vehicle air conditioner is an automatic air conditioner which includes an air conditioning unit 1 and an air-conditioning electronic control unit (A/C ECU) 10. The air conditioning unit 1 can independently control an air temperature in a driver-seat side area (e.g., right side area in a right steering wheel) and an air temperature in a passenger-seat side area (e.g., left side area in the right steering wheel). Here, in the vehicle having the right steering wheel, the driver-seat side area includes a rear seat on the right side of the vehicle, and the passenger-seat side area includes a rear seat on the left side of the vehicle. The air conditioning unit 1 can also independently change an air outlet mode in the

driver-seat side area and the passenger-seat side area. Further, the A/C ECU 10 controls each actuator in the air conditioning unit 1 so as to control air-conditioning operation of the air conditioning unit 1.

5 Specifically, the air conditioning unit 1 includes an air duct 2 which is provided on a front side of the passenger compartment. An inside-outside air switching door 3 and a blower 4 are provided on an upstream air side of the air duct 2. The inside-outside air switching door 3 is driven by the actuator (e.g., servo motor 10 5) and changes an opening degree of each of an inside air introduction port 6 and an outside air introduction port 7.

 The blower 4 is a centrifugal electrical blower that is driven and rotated by a blower motor 9 controlled by a blower driving circuit 8. In the air duct 2, the blower 4 generates an air flow 15 toward the passenger compartment.

 An evaporator (cooling heat exchanger) 41, which cools air flowing through the air duct 2, is provided in the air duct 2 downstream of the blower 4. Further, a heater core (heating heat exchanger) 42 is provided in the air duct 2 on a downstream air 20 side of the evaporator 41. The heater core 42 heats air flowing therethrough in first and second air passages 11, 12 by exchanging heat with cooling water (hot water) of the engine for driving. Here, the first and second air passages 11, 12 are separated by a division plate 14. Further, a Peltier element can be also used 25 as the evaporator 41 when the air conditioner is used for a vehicle driven by electric power.

 A driver-seat side air mixing door (driver-seat side A/M door)

15 and a passenger-seat side air mixing door (passenger-seat side
A/M door) 16 are provided on an upstream air side of the heater
core 42. The driver-seat side A/M door 15 independently controls
an air temperature to be blown into the driver-seat side area of
the passenger compartment, and the passenger-seat side A/M door
16 independently controls an air temperature to be blown into the
passenger-seat side area of the passenger compartment. The driver
and passenger-seat side A/M doors 15, 16 are driven by the actuators
(e.g., servomotors 17, 18) and control a temperature of conditioned
air blowing from driver and passenger-seat side air outlets to
the driver and passenger-seat side areas respectively. More
particularly, the temperature of conditioned air blown toward inner
surfaces of front windshield on the driver and passenger-seat sides
are respectively controlled. The driver and passenger-seat side
air outlets will be explained below.

Here, the evaporator 41 according to the first embodiment
of the present invention is a part of a refrigerant cycle 400 and
evaporates refrigerant which is decompressed and expanded by an
expansion valve 440. Further, the refrigerant cycle 400 includes
an electric compressor 410, a condenser 420, a gas-liquid separator
430, the above-described expansion valve 440 and refrigerant piping
which connects the above-described parts circularly. In the
refrigerant cycle 400, refrigerant discharged from the electric
compressor 410 flows into the condenser 420 to be liquefied and
condensed. Then, the gas-liquid separator 430 separates the
liquefied and condensed refrigerant from the condenser 420 into
gas refrigerant and liquid refrigerant, so that only the liquid

refrigerant flows downstream. Then, the expansion valve 440 decompresses and expands the liquid refrigerant from the gas-liquid separator 430.

5 In the refrigerant cycle 400, the electric compressor 410 compresses and discharges refrigerant. The electric compressor 410 includes an electric motor 460 and an inverter 470. The electric motor 460 drives the electric compressor 410. For example, a three-phase induction motor is used as the electric motor 460. The inverter 470, to which a battery B supplies electric power, 10 changes a rotation speed of the electric motor 460 according to a driving frequency calculated by the A/C ECU 10.

Accordingly, the electric compressor 410 changes the amount of refrigerant discharged from its discharge port to the condenser 420 by changing a rotation speed of the electric motor 460. Thus, 15 a cooling capacity of the evaporator 41 can be controlled by controlling the amount of refrigerant circulated in the refrigerant cycle 400, that is, the amount of refrigerant flowing into the evaporator 41.

20 A driver-seat side defroster air outlet 20, a driver-seat side center-face air outlet 21, a driver-seat side side-face air outlet 22 and a driver-seat side foot air outlet 23 are opened at downstream ends of air ducts connected to a downstream air side of the first air passage 11 (FIG. 1).

25 Further, a passenger-seat side defroster air outlet 30, a passenger-seat side center-face air outlet 31, a passenger-seat side side-face air outlet 32 and a passenger-seat side foot air outlet 33 are opened at downstream ends of air ducts connected

to a downstream air side of the second air passage 12 (FIG. 1). Here, the driver and passenger-seat side defroster air outlets 20, 30 are air outlets for blowing conditioned air (mainly, warm air) to the front windshield at the right and left sides. The right and left side side-face air outlets 22, 32 are air outlets for blowing conditioned air (mainly, warm air) to right and left side windowpanes.

Then, driver and passenger-seat side air-outlet mode switching doors 24-26, 34-36 are provided in the first and second air passage 11, 12. The air outlet mode on each of the driver and passenger-seat sides can be set independently by using these doors 24-26, 34-36. Further, these doors 24-26, 34-36 are driven by the actuators (e.g., servo motors 28, 29, 38, 39). Here, the vehicle air conditioner has a face mode, a bi-level mode, a foot mode and a defroster mode, for example, as the air outlet mode on the driver-seat side and the air outlet mode on the passenger-seat side.

The A/C ECU 10 is supplied with DC power from the battery B and performs some control operation, such as air conditioning control in the passenger compartment while the vehicle drives and air conditioning control in the passenger compartment while the vehicle stops. The control while the vehicle stops will be described below. As shown in FIG. 1, the A/C ECU 10 receives switching signals from operation switches on an air-conditioning operation panel 51 integrally provided in a dashboard 50. Further, the A/C ECU 10 receives sensor input signals from sensors described below.

As shown in FIG. 2, the air-conditioning operation panel 51 has a liquid crystal display 52, an inside-outside air selecting switch 53, a front defroster switch 54, a rear defroster (defogger) switch 55, a DUAL switch 56, an air outlet mode selecting switch 57, an blower air amount setting switch 58, an A/C switch 59, an AUTO switch 60, an OFF switch 61, a driver-seat side air temperature setting switch 62, a passenger-seat side air temperature setting switch 63 and a fuel consumption improving switch 64, etc.

The air outlet mode selecting switch 57 is used for setting the air outlet mode to any one of the face mode, the bi-level mode, the foot mode and the defroster mode according to a user manual operation. Further, the air outlet mode selecting switch 57 is used for setting an air-conditioning state while the vehicle stops according to a user manual operation. Here, the air-conditioning state while the vehicle stops is indicated by a controlling level ("strong", "weak", "no setting") of air-conditioning in the passenger compartment.

Further, the driver-seat side air temperature setting switch 62 is used for setting a temperature in the driver-seat side area of the passenger compartment to a desired temperature. The passenger-seat side air temperature setting switch 63 is used for setting a temperature in the passenger-seat side area of the passenger compartment to a desired temperature.

The A/C ECU 10 is connected with a driver-seat side inside air temperature sensor 71, a passenger-seat side inside air temperature sensor 72, an outside air temperature sensor 73 and a post-evaporator temperature sensor 74 and a water temperature

sensor 75. The driver-seat side inside air temperature sensor 71 detects an inside air temperature in the driver-seat side area, and the passenger-seat side inside air temperature sensor 72 detects an inside air temperature in the passenger-seat side area. The outside air temperature sensor 73 detects an outside air temperature. The post-evaporator temperature sensor 74 detects a temperature of air blown immediately from the evaporator 41. The water temperature sensor 75 detects a temperature of engine cooling water.

Here, the inside air temperature sensors 71, 72 are arranged integrally in the dashboard 50 as shown in FIGS. 3 and 4. The driver-seat side inside air temperature sensor 71 detects a temperature in an area R1 (FIG. 5) including a seat surface on the driver-seat side in non-contact. Further, the driver-seat side inside air temperature sensor 71 has a sensor element which is arranged so that a light receiving surface points to the area R1. The sensor element of the driver-seat side inside air temperature sensor 71 outputs an electric signal according to a quantity of infrared rays radiated from the area R1.

The passenger-seat side inside air temperature sensor 72 detects a temperature in an area R2 (FIG. 5) including a seat surface on the passenger-seat side in non-contact. Further, the passenger-seat side inside air temperature sensor 72 has a sensor element which is arranged so that a light receiving surface points to the area R2. The sensor element of the passenger-seat side inside air temperature sensor 72 outputs an electric signal according to a quantity of infrared rays radiated from the area

R2.

Here, each of the inside air temperature sensors 71, 72 is a thermo pile type infrared ray sensor. Each of the inside air temperature sensors 71, 72 includes a temperature sensor (not shown) for detecting an absolute temperature of each inside air temperature sensor itself. Further, a temperature sensing element (e.g., thermistor) is used for each of the outside air temperature sensor 73, the post-evaporator temperature sensor 74 and the water temperature sensor 75.

Further, the A/C ECU 10 is connected with a keyless ECU 200. The keyless ECU 200 automatically transmits a transmitting signal by a radio-wave at certain intervals. An electronic key 300 transmits a returning signal whenever it receives the transmitting signal from the keyless ECU 200.

For example, if a user having the electronic key 300 comes to the vehicle to get on, the keyless ECU 200 unlocks a vehicle door by using a lock device 210 because the keyless ECU 200 receives the returning signal from the electronic key 300. Further, if the user having the electronic key 300 goes away from the vehicle beyond a certain distance, the electronic key 300 does not receive the transmitting signal from the keyless ECU 200 and does not transmit the returning signal to the keyless ECU 200. That is, no signal is exchanged between the keyless ECU 200 and the electronic key 300. If this situation continues for a certain period, the keyless ECU 200 locks the door.

Next, as an example of operation according to the first embodiment of the present invention, an air conditioning control

of the A/C ECU 10 while the vehicle stops will be described below with reference to FIG. 6.

The A/C ECU 10 performs air conditioning control operation according to a flowchart in FIG. 6. The air conditioning control operation starts when an ignition switch IG is switched off and is repeated at certain intervals (e.g., 250 msec). The ignition switch IG is used for giving permission to supply electric power to a driving equipment such as the engine and the electric motor.

Firstly, the A/C ECU 10 determines whether a distance between the user and the vehicle is smaller than a certain distance D1 (e.g., 50 m) or not (S100). For example, the A/C ECU 10 determines received power of the returning signal received on the keyless ECU 200 and determines whether the received power is larger than a predetermined power P. When the received power is larger than the predetermined power P, the A/C ECU 10 determines that the distance between the user and the vehicle is smaller than the certain distance D1, and the determination at step S100 is "YES". The received power is referred to as $F(t)$ below, and "t" indicates time (multiples of 250 msec).

Next, the A/C ECU 10 determines whether the user comes to the vehicle or not (S110). For example, the A/C ECU 10 compares a received power $F(t)$ at the present time and a received power $F(t-5)$ at the time before 5 seconds from the present time. When the received power $F(t)$ is larger than the received power $F(t-5)$, the A/C ECU 10 determines that the user comes to the vehicle, and the determination at step S110 is "YES".

Next, the A/C ECU 10 determines whether a terminal voltage

(battery voltage) of the battery B is larger than 12 V or not (S120). That is, the A/C ECU 10 determines whether capacity of the battery B is sufficient or not for controlling an air condition in the passenger compartment while the vehicle stops, that is, when a vehicle generator does not generate.

When the terminal voltage of the battery B is larger than 12 V, the A/C ECU 10 determines that capacity of the battery B is sufficient. Then, the A/C ECU 10 receives a driver-seat side temperature (i.e., temperature T(R1) detected by an infrared ray sensor in the driver-seat side area R1) from the driver-seat side inside air temperature sensor 71 (S130). Next, in order to determine a timing to start the air conditioning control, the A/C ECU 10 determines whether the detected temperature T(R1) is larger than a predetermined temperature 28 °C (S140). When the detected temperature T(R1) is larger than 28 °C, the A/C ECU 10 determines that the air conditioning control needs to be started, and the determination at step S140 is "YES". That is, the A/C ECU 10 determines that the present time is the timing to start the air conditioning control. Further, when the detected temperature T(R1) is smaller than 28 °C, the A/C ECU 10 determines that the air conditioning control should not be started, and the determination at step S140 is "NO".

Then, when the determination at step S140 is "YES", the A/C ECU 10 determines whether the air condition setting while the vehicle stops is set to "strong" by the air outlet mode selecting switch 57 (S150).

When the air condition setting while the vehicle stops is

"strong", the A/C ECU 10 determines whether the terminal voltage of the battery B is larger than 11.5 V or not (S160). That is, the A/C ECU 10 determines again whether the remaining capacity of the battery B is sufficient or not for performing the air conditioning control in the passenger compartment while the vehicle stops. If the terminal voltage of the battery B is larger than 11.5 V, the A/C ECU 10 determines that the remaining capacity of the battery B is sufficient for performing the air conditioning control. In this case, the A/C ECU 10 starts and performs a full automatic air-conditioning operation (S170). This full automatic air-conditioning operation continues for a predetermined period (e.g., 1 min).

Firstly, in the full automatic air-conditioning operation, the A/C ECU 10 calculates a driver-seat side target air temperature TAO(Dr) and a passenger-seat side target air temperature TAO(Pa).

Specifically, the TAO(Dr) and TAO(Pa) are calculated respectively by using a temperature TIR(Dr) detected by the driver-seat side inside air temperature sensor 71, a temperature TIR(Pa) detected by the passenger-seat side inside air temperature sensor 72, a temperature TSET(Dr) set by the driver-seat side air temperature setting switch 62, a temperature TEST(Pa) set by the passenger-seat side air temperature setting switch 63 and a temperature TAM detected by the outside air temperature sensor 73, in accordance with the following equations 1 and 2.

(equation 1)

$$TAO(Dr) = Kset \times TSET(Dr) - Kir \times TIR(Dr) - Kam \times TAM + C$$

(equation 2)

$$TAO(Pa) = Kset \times TSET(Pa) - Kir \times TIR(Pa) - Kam \times TAM + C$$

where, Kset : temperature setting coefficient (e.g., 7.0)

Kir : infrared ray coefficient (e.g., 5.1)

Kam : outside air temperature coefficient (e.g., 1.0)

C : compensation coefficient (e.g., -45)

Next, the A/C ECU 10 calculates a blower voltage VA, which corresponds to air blowing amount of the blower 4 and is applied to the blower motor 9, based on TAO(Dr) and TAO(Pa) calculated above. Firstly, the A/C ECU 10 calculates blower voltage VA(Dr) and VA(Pa) in order to calculate the blower voltage VA. Specifically, VA(Dr) and VA(Pa) are calculated by using TAO(Dr) and TAO(Pa), respectively based on the characteristic graph in FIG. 7. Then, the blower voltage VA is calculated by averaging VA(Dr) and VA(Pa).

Next, the A/C ECU 10 determines the air outlet mode on each of the driver and passenger-seat sides based on TAO(Dr), TAO(Pa) and the characteristic graph in FIG. 8.

When the A/C ECU 10 determines the face mode as the driver-seat side air outlet mode, only the air outlets 21, 22 are opened. When the foot mode is determined as the driver-seat side air outlet mode, only the air outlet 23 is opened. When the bi-level mode is determined as the driver-seat side air outlet mode, the air outlets 21-23 are opened. Then, when the face mode is determined as the passenger-seat side air outlet mode, only the air outlets 31, 32 are opened. When the foot mode is determined as the passenger-seat side air outlet mode, only the air outlet 33 is

opened. When the bi-level mode is determined as the passenger-seat side air outlet mode, the air outlets 31-33 are opened.

Next, the A/C ECU 10 averages $TAO(Dr)$ and $TAO(Pa)$ calculated above and obtains an average target air temperature $TAOe$ by using a formula of $TAOe = (TAO(Dr) + TAO(Pa)) / 2$. Then, based on the $TAOe$ and the characteristic graph in FIG. 9, the A/C ECU 10 determines a target air flow ratio between an inside air amount introduced from the inside air introduction port 6 and an outside air amount introduced from the outside air introduction port 7. That is, the A/C ECU 10 determines a target opening degree $SW1$ (target operation position) of the inside-outside air switching door 3. In FIG. 9, when the target opening degree $SW1$ is "100%" (FRS), only outside air is introduced by the inside-outside air switching door 3. To the contrary, when the target opening degree $SW1$ is "0%" (REC), only inside air is introduced by the inside-outside air switching door 3.

Next, the A/C ECU 10 determines that a driver-seat side A/M door opening degree $SW(Dr)$ (i.e., opening degree of the driver-seat side A/M door 15) is "100%". Further, the A/C ECU 10 determines that a passenger-seat side A/M door opening degree $SW(Pa)$ (i.e., opening degree of the passenger-seat side A/M door 16) is "100%".

Next, the A/C ECU 10 outputs a signal corresponding to the blower voltage VA to the blower driving circuit 8. Further, the A/C ECU 10 outputs control signals which correspond to the air outlet mode, the $SW(Dr)$, the $SW(Pa)$ and the target opening degree of the inside-outside air switching door 3, to corresponding one of the servo motors 5, 17, 18, 28, 29, 38, 39 and the electric

motor 460.

In addition, the A/C ECU 10 determines a control value (motor control signal) for controlling the electric motor 460 of the electric compressor 410 based on a temperature detected by the post-evaporator temperature sensor 74. The amount of refrigerant flowing into the evaporator 41 is changed by controlling the electric motor 460 of the electric compressor 410 based on the determined motor control value. Thus, the temperature detected by the post-evaporator temperature sensor 74 can be adjusted to a target temperature.

As described above, the air condition in the passenger compartment is controlled by the operation of each of the electric motor 460 of the electric compressor 410 and the servo motors.

Further, when the air condition setting while the vehicle stops is not "strong" (determination at step S150 is "NO" in FIG. 6) and is "weak" (determination at step S161 is "YES"), a ventilation operation is performed (S162). Further, this ventilation operation continues for a predetermined period (e.g., 1 min).

In this case, the A/C ECU 10 determines the target opening degree of the inside-outside air switching door 3 so that an inside air amount introduced from the inside air introduction port 6 is "0%" (full close) and an outside air amount introduced from the outside air introduction port 7 is "100%" (full open). That is, in the ventilation operation, the inside-outside air switching door 3 fully closes the inside air introduction port 6 and fully opens the outside air introduction port 7, so that the passenger compartment is ventilated by outside air. The A/C ECU 10 outputs

a control signal corresponding to the determined target opening degree to the servo motor 5.

Further, the A/C ECU 10 outputs a predetermined signal corresponding to the blower voltage VA to the blower driving circuit 8.

In addition, in the ventilation operation, the A/C ECU 10 determines the bi-level mode as the air outlet mode on each of the driver and passenger-seat sides and outputs a control signal corresponding to the determined air outlet mode to the servo motors 17, 18, 28, 29, 38, 39.

As described above, outside air is introduced in the passenger compartment and the ventilation operation is performed by operating each of the servo motors 5, 17, 18, 28, 29, 38, 39 and the electric motor 460.

Further, when the air condition setting while the vehicle stops is not either the "strong" or the "weak" at step S161, either the ventilation operation or the air-conditioning operation is not performed in the passenger compartment.

Next, advantages of the vehicle air conditioner according to the first embodiment of the present invention will be described below.

(1) The non-contact temperature sensors 71, 72 are used as the inside air temperature sensors. Further, based on the infrared rays radiated from each of the driver and passenger-seat side areas R1, R2, each of these sensors 71, 72 detects a surface temperature in corresponding one of the areas R1, R2 in non-contact. Therefore, it is not necessary to blow air from the passenger compartment

to each of the non-contact temperature sensors 71, 72 in order to detect an air temperature in the passenger compartment by using each of the sensors 71, 72.

Thus, energy consumption due to air blowing can be reduced while the temperature in the passenger compartment can be accurately detected. Accordingly, the vehicle air conditioner can accurately determine a timing to start air-conditioning by the air conditioning unit 1 while the energy consumption can be effectively prevented. Thus, a temperature rise can be prevented in the passenger compartment while energy consumption can be reduced.

(2) In the vehicle air conditioner according to the first embodiment of the present invention, the ventilation operation is performed in case where the air-conditioning while the vehicle stops is set to "weak", even if the temperature detected by the driver-seat side inside air temperature sensor 71 is higher than 28 °C. That is, the driver-seat side inside air temperature sensor 71 is used for determining whether the ventilation due to the air conditioning unit 1 needs to be started or not, that is, for determining a timing to start the ventilation operation. Accordingly, the vehicle air conditioner can accurately determine the timing to start ventilation operation due to the air conditioning unit 1 while energy consumption can be reduced.

(3) The air outlet mode selecting switch 57 is provided to select the controlling level of air condition among the "strong", the "weak", the "no setting" in advance. Therefore, the air condition in the passenger compartment can be controlled so as

to fit a passenger's preference before the user gets on the vehicle. Especially, if the controlling level of air condition is set to the "weak", it is possible to reserve the ventilation operation due to the air conditioning unit 1. Therefore, it is useful for a user who prefers only ventilation.

(4) If a distance between the user and the vehicle is smaller than a certain distance D_1 and the user comes to the vehicle, the vehicle air conditioner determines whether the air conditioning control by the air conditioning unit 1 should be started or not. Therefore, the air conditioning control is performed only when possibility of approach of the user is high. Accordingly, energy consumption can be minimized because the air conditioning control is performed only when it is necessary.

(5) Generally, a passenger is especially sensitive to a temperature of a seat when the passenger sits on the seat. In the first embodiment, each of the inside air temperature sensors 71, 72 is the non-contact temperature sensor which detects the surface temperature of corresponding one of areas including the driver and passenger seats in non-contact. Therefore, the vehicle air conditioner determines the start operation of the air conditioning control due to the air conditioning unit 1 to be fitted to a passenger's thermal feeling.

Further, the on-off control of the ventilation operation of the passenger compartment is performed in the vehicle air conditioner according to the first embodiment of the present invention. However, for example, strong-weak control of a ventilating capacity can be also performed in a ventilation system

which ventilates a passenger compartment normally.

(Second Embodiment)

In the above-described first embodiment of the present invention, one of the ventilation operation and the air-conditioning operation can be selected for setting the air-conditioning state while the vehicle stops by the air outlet mode selecting switch 57. To the contrary, only the ventilation operation can be performed in a vehicle air conditioner according to the second embodiment of the present invention.

In the second embodiment, the A/C ECU 10 performs air conditioning control operation according to the flowchart in FIG. 10. The air conditioning control operation starts when the ignition switch IG is switched off and is repeated at certain intervals (e.g., 60 msec).

Firstly, the A/C ECU 10 determines whether the terminal voltage (battery voltage) of the battery B is larger than 12 V or not (S120). When the terminal voltage of the battery B is larger than 12 V, the A/C ECU 10 receives a driver-seat side temperature TIR(Dr) detected by the driver-seat side inside air temperature sensor 71 (S130A). The blower voltage VA is determined based on the detected temperature TIR(Dr) (i.e., temperature detected by the infrared ray sensor at the driver-seat side) and the characteristic graph shown in FIG. 10. That is, the blower voltage VA increases stepwisely as the temperature TIR(Dr) detected by the driver-seat side inside air temperature sensor 71 increases.

Further, the A/C ECU 10 determines the target opening degree of the inside-outside air switching door 3 so that an air amount

introduced from the inside air introduction port 6 is "0%" (full close) and an air flow introduced from the outside air introduction port 7 is "100%" (full open). The A/C ECU 10 outputs a control signal corresponding to the determined target opening degree to the servo motor 5.

In addition, the A/C ECU 10 determines the bi-level mode as the air outlet mode on each of the driver and passenger-seat sides and outputs a control signal corresponding to the determined air outlet mode to the servo motors 17, 18, 28, 29, 38, 39.

As described above, outside air is introduced in the passenger compartment and the ventilation operation is performed by operating each of the servo motors 5, 17, 18, 28, 29, 38, 39 and the electric motor 460.

As described above, in the vehicle air conditioner according to the second embodiment of the present invention, the blower voltage VA increase stepwisely as the temperature TIR(Dr) detected by the driver-seat side inside air temperature sensor 71 increases. Accordingly, the amount of blown air increases stepwisely as the temperature detected by the driver-seat side inside air temperature sensor 71 increases. Therefore, air condition in the passenger compartment can be finely controlled according to the detected temperature in the passenger compartment.

Although the present invention has been fully described in connection with the preferred embodiments thereof with reference to the accompanying drawings, it is to be noted that various changes and modifications will become apparent to those skilled in the art. For example, in the above-described second embodiment, the

blower voltage VA can be controlled to increase continuously as the temperature TIR(Dr) detected by the infrared ray sensor at the driver side increases.

In the above-described embodiments, the air outlet mode selecting switch 57 is used as a reservation means for reserving the ventilation operation and a selecting means for selecting an air-conditioning level. However, the other devices can be used as the reservation means and the selecting means. Further, in the above-described embodiments, the air conditioning unit 1 corresponds to each of a ventilating unit and an air conditioning unit of the present invention.

Such changes and modifications are to be understood as being included within the scope of the present invention as defined by the appended claims.